


Детализировка и лист запасных частей FROSP F625



No.	DESCRIPTION	QTY	No.	DESCRIPTION	QTY
1	BOLT (M5X25)	4	39	BOLT (M5X16)	2
2	EXHAUST CAP	1	40	BOLT (4X10)	2
3	RECTANGLE WASHER	1	41	GUIDE PLATE	1
4	COMPRESSION SPRING	1	42	SCREW (M4)	3
5	O-RING	1	43	LEFT MAGZINE CAP	1
6	CYLINDER CAP	1	44	POSITON GRADUATION PIECE	1
7	CYLINDER CAP SEAL	1	45	SETTING PIECE	1
8	HEAD VALVE PISTON	1	46	RIGHT MAGZINE CAP	1
9	O-RING	1	47	BOLT (M4X10)	3
10	O-RING	1	48	BOLT (M4X6. 2)	2
11	O-RING	1	49	LEFT REGULATOR SHELL	1
12	O-RING	1	50	SCREW (M5)	1
13	DRIVER UNIT	1	51	LEFT SUPPORT STAND	1
14	O-RING	1	52	SCREW (M4)	1
15	COLLAR	1	53	BUCKLE PIN	1
16	O-RING	1	54	BOLT (M5X18)	1
17	CYLINDER	1	55	RIGHT SUPPORT STAND	1
18	BUMPER	1	56	BOLT (M4X12)	2
19	BODY	1	57	BOLT (M2. 5X4)	1
20	NOZZLE	1	58	REGULATE PIECE	1
21	RUBBER HANDLE CASE	1	59	REGULATE GEAR	1
22	O-RING	1	60	RIGHT REGULATOR SHELL	1
23	END CUP	1	61	BOLT (M4X6. 2)	2
24	AIR PIUG	1	62	STEEL BALL	2
25	AIR PIUG SEAT	1	63	REGULATOR SPRING	2
26	SEAL	1	64	REGULATOR	1
27	TRIGGER VALVE SEAT	1	65	BOLT (M4X9)	1
28	O-RING	1	66	STOP COLLAR	1
29	INNER VALVE SEAT	1	67	PUSHER	1
30	O-RING	1	68	BACK NOSE ASSEMBLY	2
31	TRIGGER VALVE GUIDE	1	69	PUSHER GUIDE	2
32	TRIGGER SPRING	1	70	PUSHER SPRING	2
33	TRIGGER LOCK	1	71	LATCH	1
34	TRIGGER	1	72	LATCH SPRING	1
35	O-RING	1	73	O-RING	1
36	TRIGGER PIN	1	74	TRIGGER PIN	1
37	BOLT (M4X8)	2	75	DECORATION BOARD	1
38	COVER PLATE	1	76	BOLT (MX10)	2